

HEAVY DUTY TYRE SEALANT

Maximise uptime by
reducing the risk of
punctures across
your machinery fleet

- ✓ Continuous protection against flat tyres
- ✓ Reduce fuel costs by maintaining correct tyre pressure
- ✓ Suitable for on-road highway truck tyres and all pneumatic off-road applications - including tractors, forklifts, excavators, mowers and all-terrain vehicles
- ✓ Water-soluble gel - containing rubber crumb for maximum effect. Can be washed out with water, using normal tap pressure
- ✓ Environmentally friendly - non-hazardous, non-flammable and non-toxic
- ✓ Harmless to tyre and rim
- ✓ Manufactured in the UK

Comes in flexi packs or drums:

Flexi Pack (1l) Spout nozzle fits over the tyre valve stem.

Drums (20 litres) to be used with a tyre sealant application pump

Quantity used is according to tyre size

www.redstoneuk.com

REDWING®

DRIVEN BY SUPERIOR STRENGTH, QUALITY AND VALUE

Due to the ever-increasing demands from vehicle operators on their vehicle tyres, the market is constantly looking for ways of reducing the downtime caused by punctures and getting maximum life from their tyres.

Tyre sealant is becoming increasingly recognised across industries and fleets as the ideal solution to dealing with punctures cost effectively.

With the Redwing Heavy Duty Tyre Sealant, the cost of protecting a four-wheeled vehicle is considerably less than replacing a single tyre.



Redwing Heavy Duty Tyre Sealant seals the puncture as it happens, ensuring the vehicle can continue to operate as normal. Under inflated tyres have an impact on the vehicle's fuel consumption, due to increased rolling resistance generated by additional heat build up within the tyre. Easy to apply, anywhere on site without specialist tools or knowledge!

How to use it. Park machine with valve at the top of the tyre and remove valve core, using a valve core tool. Attach nozzle of pump (or spout if using Flexi Pack) and pump in the required amount of sealant into the tyre. One pump of the handle inserts 100ml of sealant. Remove nozzle, insert valve core and reinflate tyre to the correct pressure. Tyres containing Redwing sealant can be removed from the wheel in the normal way and repaired to the industry standards, should a permanent repair be required.

Application Chart



SIZE	LITRE	SIZE	LITRE	SIZE	LITRE	SIZE	LITRE
4 Inch		14 Inch		20 Inch		30 Inch	
9x3.50-4	0.65	27x9.00R14	1.75	9.00-20	2.50	420/70R30	6.00
11x4.00-4	0.65	27x11.00R14	2.00	9.5-20	2.50	16.9R30	7.00
5 Inch		185R14	1.50	10.00-20	2.75	480/70R30	7.50
11x4.00-5	0.65	195R14	1.50	11.00-20	3.00	520/70R30	8.00
4.10/3.50-5	0.65	205R14	1.75	12.00-20	3.25	32 Inch	
6 Inch		15 Inch		12.50-20	3.25	12.4R32	4.75
13x5.00-6	0.90	8.25-15	2.00	41x14.00-20	4.00	24.5-32	11.50
145/70-6	0.90	27x8.50-15	1.75	14.5-20	4.25	650/75R32	11.50
13x6.50-6	0.90	12.00-15	2.50	16.0/70-20	4.75	30.5R32	14.50
15x6.00-6	0.90	29x12.50-15	2.75	24 Inch		34 Inch	
8 Inch		31x13.50-15	3.25	8.3-24	2.25	16.9R34	7.00
4.80/4.00-8	0.90	33x12.50-15	3.00	11.2-24	3.50	18.4R34	7.75
16x6.50-8	1.00	36x13.50-15	3.50	12.00-24	4.00	480/70R34	7.75
16x7.50-8	1.00	15.3 Inch		12.4/11-24	3.25	23.1-34	10.25
18x8.50-8	1.50	10.0/75-15.3	2.50	13.6R24	4.25	36 Inch	
18x9.50-8	1.50	11.5/80-15.3	2.50	360/70R24	4.25	11.2-36	4.25
20x10.00-8	1.50	12.5/80-15.3	3.00	14.9R24	5.00	12.4R36	4.75
22x11.00-8	2.00	16 Inch		420/70R24	5.25	13.6R36	5.50
9 Inch		5.50-16	1.25	15.5/80-24	5.50	38 Inch	
20x10.00-9	1.50	6.00-16	1.25	16.9R24	5.75	12.4-38	5.00
22x11.00-9	2.00	6.50-16	1.50	19.5-24	6.75	13.6R38	5.75
25x12.00-9	2.00	7.50-16	1.75	21-24	7.75	14.9R38	5.75
10 Inch		9.00-16	2.25	25 Inch		16.9R38	7.50
7.50-10	1.60	9.50-16	2.25	15.25R25	5.50	480/70R38	8.25
18x8.50-10	1.50	10.00-16	2.50	17.5R25	6.50	18.4R38	8.75
20x10.00-10	1.75	10.5/65-16	2.50	26.5-25	12.50	520/70R38	9.25
20x12.00-10	1.75	13.6-16	3.50	26 Inch		20.8R38	9.75
22x11.00-10	1.75	14.0/65-16	3.50	16.9-26	6.00	580/70R38	10.50
24x12.00-10	2.50	16.50-16	4.50	18.4-26	7.00	42 Inch	
11 Inch		16.5 Inch		23.1-26	9.75	16.9R42	7.75
24x8.00-11	1.75	10-16.5	2.50	28.1-26	11.50	20.8R42	10.50
24x10.00-11	2.00	12-16.5	3.00	28 Inch		46 Inch	
12 Inch		17 Inch		11.2-28	3.75	12.4R46	5.50
5.00-12	1.00	15.0/55-17	3.50	13.6-28	4.75	51 Inch	
6.00-12	1.00	19.0/45-17	4.50	360/70R28	4.75	33.00-51	25.50
7.00-12	1.75	18 Inch		14.9R28	5.00	36.00-51	29.50
23x10.50-12	2.00	10.5/80-18	2.75	380/70R28	5.00		
24x12.00-12	2.00	12.5/80-18	3.25	420/70R28	5.75		
24x13.00-12	2.25	15.0/70-18	4.00	16.9R28	6.00		
25x8.00-12	1.75	19 Inch		480/70R28	7.00		
25x10.00-12	2.00	4.00-19	1.25	18.4-28	7.25		
26x12.00-12	2.25	6.00-19	1.75				
		7.00-19	1.75				

Size missing? Work out volume by using the following formula:

Tyre height x tyre width (inches) = x 3.14 = multiply by 0.0018 = litres per wheel



Redstone (Tyres) Ltd
South Yard, Ford Lane, Arundel
West Sussex BN18 0DF



Place your order on **01243 558959**
or email **sales@redstoneuk.com**
visit **www.redstoneuk.com**